

Oil Reservoir Sight Bottles

Oil reservoir assemblies screw in easily where the oil fill cap is located on all Hydra-Cell pumps models except the F20, P100, T100, and Q155 Series models.

Hydra-Cell pumps equipped with an oil reservoir provide additional volume for oil expansion and allow for quick visual monitoring of the oil level and its condition.

Three different bottles are available, including a 12-oz bottle with a low-level float switch that outputs a low voltage signal if the oil level in the pump housing drops.

Bottle Assemblies

Description	Part Number
12-oz (474 ml) volume sight bottle	A01-116-3400
12-oz (474 ml) volume sight bottle with low-level float switch	A01-116-3410
4-oz (119 ml) volume sight bottle	A01-116-3500

